


ITEM	Part No	DESCRIPTION	ORIGINAL REF.	PACK	
1	04.02.AS.26.15	Ugello gas tipo SN-AS.26 Ø 15	- Insulated gas nozzle Ø 15 STD	2.599.002	10
	04.02.AS.26.18	Ugello gas tipo SN-AS.26 Ø 18	- Insulated gas nozzle Ø 12	2.599.003	10
2	04.01.M840.08	Punta guidafile M8x40 Ø 0,8	- Contact tip M8x40 Ø 0,8	147.010.108	100
	04.01.M840.10	Punta guidafile M8x40 Ø 1,0	- Contact tip M8x40 Ø 1,0	147.010.110	100
	04.01.M840.12	Punta guidafile M8x40 Ø 1,2	- Contact tip M8x40 Ø 1,2	147.010.112	100
	04.01.M840.08H	Punta guidafile M8x40 CUCRZR Ø 0,8	- Contact tip M8x40 CUCRZR Ø 0,8	147.020.108	100
	04.01.M840.10H	Punta guidafile M8x40 CUCRZR Ø 1,0	- Contact tip M8x40 CUCRZR Ø 1,0	147.020.110	100
	04.01.M840.12H	Punta guidafile M8x40 CUCRZR Ø 1,2	- Contact tip M8x40 CUCRZR Ø 1,2	147.020.112	100
3	04.05.WS35	Diffusore gas Cu	- Gas diffuser	2.599.033	10
4	11.03.RH302	Rondella isolante	- Washer	151.105.107	10
5	04.33.WS35	Portaugello	- Gas nozzle holder	2.599.041	
	04.55.WS35	Anello elastico	- Ring		
6	04.06.WS35S	Corpo torcia STD. senza portaugello	- Torch head without outside nozzle	-	1
	04.06.WS35	Corpo torcia STD. con portaugello	- Torch head with outside nozzle	2.599.048	1
	11.07.RH302	Tubo isolante lancia	- Conductor tube insulaton	140.104.130	10
7	11.21.RM360.3	Portaguaina MT.3	- Wire conduit mt.3	145.040.301	1
	11.21.RM360.4	Portaguaina MT.4	- Wire conduit mt.4	145.040.401	1
	11.21.RM360.5	Portaguaina MT.5	- Wire conduit mt.5		1
8	11.24.RH503.3	Cavo P.C. MT 3	- Power cable mt.3	112.050.301	1
	11.24.RH503.4	Cavo P.C. MT 4	- Power cable mt.4	112.050.401	1
	11.24.RH503.5	Cavo P.C. MT 5	- Power cable mt.5		1
9	04.00.KTH35.3	Kit di riparazione SH353	- Repairing Kit SH353		
	04.00.KTH35.4	Kit di riparazione SH354	- Repairing Kit SH354		
	04.00.KTH35.5	Kit di riparazione SH355	- Repairing Kit SH355		



ITEM	Part No	DESCRIPTION	ORIGINAL REF.	PACK	
1	04.02.AS.40.17	<b>Ugello gas tipo SN-AS.40 Ø 17</b>	- Gas nozzle SN-AS.40 Ø 17	2.599.007	10
	04.02.AS.40.21	<b>Ugello gas tipo SN-AS.40 Ø 21</b>	- Gas nozzle SN-AS.40 Ø 21	2.599.008	10
2	04.01.M840.08	<b>Punta guidafile M8x40 Ø 0,8</b>	- Contact tip M8x40 Ø 0,8	147.010.108	100
	04.01.M840.10	<b>Punta guidafile M8x40 Ø 1,0</b>	- Contact tip M8x40 Ø 1,0	147.010.110	100
	04.01.M840.12	<b>Punta guidafile M8x40 Ø 1,2</b>	- Contact tip M8x40 Ø 1,2	147.010.112	100
	04.01.M840.16	<b>Punta guidafile M8x40 Ø 1,6</b>	- Contact tip M8x40 Ø 1,6	147.010.116	100
	04.01.M840.20	<b>Punta guidafile M8x40 Ø 2,0</b>	- Contact tip M8x40 Ø 2,0	147.010.120	100
	04.01.M840.08H	<b>Punta guidafile M8x40 CUCRZR Ø 0,8</b>	- Contact tip M8x40 CUCRZR Ø 0,8	147.020.108	100
	04.01.M840.10H	<b>Punta guidafile M8x40 CUCRZR Ø 1,0</b>	- Contact tip M8x40 CUCRZR Ø 1,0	147.020.110	100
	04.01.M840.12H	<b>Punta guidafile M8x40 CUCRZR Ø 1,2</b>	- Contact tip M8x40 CUCRZR Ø 1,2	147.020.112	100
	04.01.M840.16H	<b>Punta guidafile M8x40 CUCRZR Ø 1,6</b>	- Contact tip M8x40 CUCRZR Ø 1,6	147.020.116	100
04.01.M840.20H	<b>Punta guidafile M8x40 CUCRZR Ø 2,0</b>	- Contact tip M8x40 CUCRZR Ø 2,0	147.020.120	100	
3	04.05.WS53	<b>Diffusore gas Cu</b>	- Gas diffuser	2.599.034	10
4	11.03.RH503	<b>Rondella isolante</b>	- Washer	151.105.106	10
5	04.33.WS53	<b>Portaugello</b>	- Gas nozzle holder	2.599.042	5
	04.55.WS53	<b>Anello elastico</b>	- Ring		10
6	04.06.WS53S	<b>Corpo torcia STD. senza portaugello</b>	- Torch head without outside nozzle		1
	04.06.WS53	<b>Corpo torcia STD. con portaugello</b>	- Torch head with outside nozzle	2.599.052	1
	11.07.RH503	<b>Tubo isolante lancia</b>	- Conductor tube insulation	140.104.502	10
7	11.21.RH503.3	<b>Portaguaina MT.3</b>	- Wire conduit MT.3	145.510.301	1
	11.21.RH503.4	<b>Portaguaina MT.4</b>	- Wire conduit MT.4	145.510.401	1
	11.21.RH503.5	<b>Portaguaina MT.5</b>	- Wire conduit MT.5		1
8	11.24.RH503.3	<b>Cavo P.C. MT 3</b>	- Power cable MT.3	112.050.301	1
	11.24.RH503.4	<b>Cavo P.C. MT 4</b>	- Power cable MT.4	112.050.401	1
	11.24.RH503.5	<b>Cavo P.C. MT 5</b>	- Power cable MT.5		1
9	04.00.KTH53.3	<b>Kit di riparazione SH533</b>	- Repairing Kit SH533		
	04.00.KTH53.4	<b>Kit di riparazione SH534</b>	- Repairing Kit SH534		
	04.00.KTH53.5	<b>Kit di riparazione SH535</b>	- Repairing Kit SH535		