



Standard Connection 1/8"G
Adaptors - Fittings Conversion Kits Look at Page 195

PER TUTTI GLI ALTRI PARTICOLARI DI RICAMBIO VEDERE TORCIA EL-120 PAG.193
FOR ALL THE OTHERS SPARE PARTS PLEASE SEE TORCH EL-120 PAGE.193

ITEM	Part No	DESCRIPTION	PACK
COMPLETE HAND TORCH 30-120A			
	PL.6N.09210HF	UNIQ TORCH EL-60-Manuale HIGH FREQUENCY 1/8" MT.6	1
	PL.6N.09211HF	UNIQ TORCH EL-60-Manuale HIGH FREQUENCY CENT. MT.6	1
	PL.6N.09210HFS	UNIQ TORCH EL-60-Manuale HIGH FREQUENCY 1/8" MT.6 TEXTILE	1
	PL.6N.09211HFS	UNIQ TORCH EL-60-Manuale HIGH FREQUENCY CENT. MT.6 TEXTILE	1
	PL.U51864	Compasso Completo - Circle Cutting attachment	1
	PL.U51802	Carrello - Cutting guide	1
	PL.6N.07925	Corpo torcia EL-60 70° - Torch head EL60 70°	1
	PL.U07100.53	1a O-Ring - O-Ring	20
	PL.HY40.06.1	1b O-Ring - O-Ring	20
	PL.6N.07925.60	1c O-Ring - O-Ring	20
	PL.U9-8111	14 Spina F Corpo Torcia - Pin housing	10
	PL.U9-8101	15 Spina M Corpo Torcia - Pin	10
	PL.U9-8112	Presca F Cavetto Comandi - Socket housing	10
	PL.U9-8102	Presca M Cavetto Comandi - Socket	10
	PL.6N.07305	18 Impugnatura senza pulsante - Handle with hout switch	1
	02.09.A.BZ	18 Pulsante - Trigger	1
	PL.6N.07926	Corpo torcia EL-60 180° - Torch head EL-60 180°	1
	PL.6N.52601	Elettrodo AIR/N2 - Electrode Air/N2	5
	PL.6N.52602	Elettrodo lungo AIR/N2 - Extender electrode Air/N2	5
	PL.6N.07928	3 Dispositivo di accensione 30-120A - Start Cartridge 30-120A	NO HF 1
	PL.6N.07929	20 Isolante per torcia con HF 30-120A - Insulator HF 30-120A	ONLY HF 1
	PL.U60060	4 Diffusore Gas 30-60A - Gas diffuser 20-60A	2
	PL.U60061	5 Diffusore Gas 60-120A - Gas diffuser 60-120A	2