



ITEM	Part No	DESCRIPTION	ORIGINAL REF.	PACK
	PLBZ31.4.14	Torcia completa mt 4 term. 1/4" - Complete torch 4 Mts (1/4" connection)	742.0046	
	PLBZ31.6.14	Torcia completa mt 6 term. 1/4" - Complete torch 6 Mts (1/4" connection)	742.0087	
	PLBZ31.4.14.S	Torcia completa mt 4 term. 1/4" con Sicurezza - Complete torch 4 Mts (1/4" connection) with safety	742.0047	
	PLBZ31.6.14S	Torcia completa mt 6 term. 1/4" con Sicurezza - Complete torch 6 Mts (1/4" connection) with safety	742.0088	
	PLBZ31K.06	Corpo torcia BZ 31/31KK - Torch head BZ 31/31KK	742.0054	
	PLBZ31K.06.S	Corpo torcia BZ 31/31KK con sicurezza - Torch head BZ 31 with safety	442P010100T+B	
	PLBZ30.08	Impugnatura completa di pulsante BZ30/31/31KK - Handgrip complete with microswitch BZ 30/31/31KK	742.0044	
	PLBZ31.01	Elettrodo L= 16,0 mm. STD - Electrode mm. 16 - Zr	742.0017	10
	PLBZ31.01.1	Elettrodo L= 15,5 mm. - Electrode mm. 15,5 - Zr	742.0016	10
	PLBZ31.01.2	Elettrodo L= 16,5 mm. - Electrode mm. 16,5 - Zr	742.0018	10
	PLBZ30.04	Molla per tipo BZ 30/31 - Spring	742.0024	10
	PLBZ31.03.M	Boccolina isolante versione molla - Spring sleeve	742.0025	10
	PLBZ31.03.HF	Boccolina isolante versione HF - Insulating sleeve for Hf version	742.0038	10
	PLBZ31.02.10	Ugello rame Ø 1,0 mm. STD - Tip Ø 1,0 mm.	742.0011	10
	PLBZ31.02.12	Ugello rame Ø 1,2 mm. - Tip Ø 1,2 mm.	742.0026	10
	PLBZ31.05	Protezione esterna BZ31 - Outside nozzle, air diffusor	742.0004	10
	PLBZ31.05.S	Protezione esterna BZ31 con sicurezza - Outside nozzle, air diffusor with safety	442P010101T+B	10
	PLTR65.04	Molla distanziatrice - Spacer spring	742.0089	10
	PLBZ31.90	Compasso completo BZ31 - Circle cutting attachment for BZ31		
	PLBZ31.90.1	Carrello BZ31 - Cutting guide for BZ31		
	PLBZ31.20.1	Pacco cavi da Mt. 4 BZ 31/BZ 31 KK - Complete cable 4 Mts (1/4" connection)		
	PLBZ31.20.2	Pacco cavi da Mt. 6 BZ 31/BZ 31 KK - Complete cable 6 Mts (1/4" connection)		