



ITEM	Part No	DESCRIPTION	ORIGINAL REF.	PACK
	PL30.ATC	a Attacco centralizzato Lato Torcia senza PINS - Central adaptor complete without PINS		
	PL30.PIN.M1	b Pin fisso maschio - femmina - Male-female Pin		20
	PL30.PIN.M2	c Pin volante a crimpare - Male Pin		20
	PL30.03	d Scatola posteriore - Box		
	PL30.04	e Ghiera posteriore - Nut		
4 pins	PL30.4P.STD	Attacco centralizzato completo - 4 PINS STD - Central adaptor complete with 4 PINS	STD	1
	PL30.4P.FRI	Attacco centralizzato completo - 4 PINS (1-3-6-9) - Central adaptor complete with 4 PINS (1-3-6-9)	FRIMAR	1
5 pins	PL30.5P.SEL	Attacco centralizzato completo - 5 PINS - Central adaptor complete with 5 PINS	SELCO	1
6 pins	PL30.6P.CEB	Attacco centralizzato completo - 6 PINS - Central adaptor complete with 6 PINS	CE 50-70-150	1
7 pins	PL30.7P.WTC	Attacco centralizzato completo - 7 PINS - Central adaptor complete with 7 PINS	WTC	1

CENTRAL ADAPTORS - MACHINE SIDE

ITEM	Part No	DESCRIPTION	ORIGINAL REF.	PACK
	PL40.ATC	a Attacco centralizzato Lato Macchina senza PINS - Central adaptor complete without PINS		1
	PL40.PIN.F	b Pin femmina con cavetto attacco Lato Macchina - Female Pin with 50 cm. cable		20
4 pins	PL40.4P.STD	Attacco centralizzato completo - 4 PINS STD - Central adaptor complete with 4 PINS	STD	1
	PL40.4P.FRI	Attacco centralizzato completo - 4 PINS (1-3-6-9) - Central adaptor complete with 4 PINS (1-3-6-9)	FRIMAR	1
5 pins	PL40.5P.SEL	Attacco centralizzato completo - 5 PINS - Central adaptor complete with 5 PINS	SELCO	1
6 pins	PL40.6P.CEB	Attacco centralizzato completo - 6 PINS - Central adaptor complete with 6 PINS	CE 50-70-150	1
7 pins	PL40.7P.WTC	Attacco centralizzato completo - 7 PINS - Central adaptor complete with 7 PINS	WTC	1